



UX4750

Get Started Guide



SpeedTalkSM Walkie-Talkie Capable



Voice Command & Driving Mode



Powerful Speakerphone



easyedgeSM Enabled



www.LGUSA.com

UX4750

TRI-MODE

PHONE OVERVIEW



USING SpeedTalkSM (ST)




> Adding a New ST Contact

1. From the **SpeedTalkSM (4)** menu, select **New ST Contact (2)** and press **OK**.
2. Enter in the 10 digit contact number, and press **OK**.
3. Enter in the contact name, and press **OK**.
4. You will receive a message that your contact info was saved.

Adding a New ST Group

1. From the **SpeedTalk (4)** menu, select **New ST Group (3)**, press **OK** and **OK** again.
2. Enter in a group name, and press **OK**.
3. Press **Left Soft Key** to save.
4. You will receive a notification that your group was created successfully.
5. Scroll down to highlight your new group, and press **OK**.
6. Press **Right Soft Key** for **Options**.
7. Select **Add buddy (2)** and press **OK** to select members to add to the group.
8. Scroll down to the member you would like to add and press **OK**.
9. You will receive a message that your contact was successfully added to the group.
10. Repeat steps until you've added all of the members you'd like.


Note: You will ONLY be able to select members to add to your groups who have been entered into your individual contact list for SpeedTalk.



> Making a ST Alert Call

An alert call sends the user an alert tone before initiating the conversation. The receiving party has the option to answer or ignore the call. Alert calls can only be sent to individuals and not groups.

1. From standby mode, press and *hold* the **SpeedTalk Key**.
2. Use the Navigation Key to highlight a name from the contacts list and press **Left Soft Key** for **Alert**.
3. Press the **SpeedTalk Key**. The receiver will hear the alert tone and receive an alert message.
4. If the receiver accepts, press and *hold* the **SpeedTalk Key** and begin speaking after you hear the ST talk tone.
5. Release the **SpeedTalk Key** when you're done speaking.



> Making a ST Barge Call

The call is connected without the incoming call alert. The voice of the caller is immediately heard.


1. From standby mode, press and *hold* the **SpeedTalk Key**.
2. Use the Navigation Key to highlight a name from the contacts list.
3. Press and *hold* the **SpeedTalk Key** and begin speaking after you hear the ST talk tone.
4. Release the **SpeedTalk Key** when you're done speaking.
5. The receiver will hear the floor available tone.



> Making a ST Group Call

Using this function, you can make a multiparty call with all the members of a SpeedTalk Group.

1. From standby mode, press and *hold* the **SpeedTalk Key**.
2. Use the Navigation Key to highlight a group from the contacts list.
3. Press and *hold* the **SpeedTalk Key** and begin speaking after you hear the ST talk tone.
4. Release the **SpeedTalk Key** when you're done speaking.
5. All members of the group will hear the floor available tone.




> Receiving a ST Alert

When you receive a SpeedTalk alert, the Buddy Alert Message appears.

1. Select **Answer** or **Ignore**.
2. If **Answer** is selected, press and *hold* the **SpeedTalk Key** and begin speaking after you hear the ST talk tone.

Activating Speakerphone

1. From standby mode, press and *hold* the side **Speakerphone Key** and “**Speaker On**” will appear on the screen.
2. To deactivate, press and *hold* the key again and “**Speaker Off**” will appear on the screen.

**Using Voice Commands**

1. From standby mode, press the side **Voice Command Key**.
2. You will be asked to “Please Say a Command.” Clearly speak a command from the list:

Call Someone: to call a contact from your phone book.

Voice Mail: to call your voicemail.

Digit Dial: to dial a phone number by speaking the digits.

Service Alerts: to check missed calls, voicemails or new messages.

Missed Calls: to check your missed calls.

Contacts: to read, create or erase a contact.

Driving: to activate speakerphone for safe, hands-free operation.

Announce: to turn on audio confirmation of menu navigation.

Time and Date: to hear the current time and date.

Phone Status: to hear status on battery usage, signal strength, service mode, GPS location and roaming.

CONNECTIVITY FEATURES

DOWNLOADING easyedgeSM CONTENT

The new UX4750 by LG can store downloaded content from **easyedgeSM**, a technology and service that allows you to download and use applications, games, ringtones and more on your phone.

**Downloading New Content From easyedge**

1. From standby mode, press the **easyedge** icon (right) on the Navigation Key and press **OK**.
2. Once the **easyedge** Shop page is displayed, select the shopping cart icon to connect. Choose from ringtones, wallpapers, games, e-mail and more.

MESSAGING

Allows you to send a text message to an e-mail address or phone number.

**Sending a SMS Message**

1. From standby mode, press the **Messages** icon (down) on the Navigation Key and select **New Message** (2).
2. Press **Left Soft Key** for **Contacts** to select a recipient from the **Contacts** (1), **Recent Calls** (2) or **Recent Addresses** (3) menu, or use the keypad to enter a new e-mail address or phone number. Up to 10 recipients can be added.
3. Select **Message** and press **OK**.
4. Enter the message (up to 160 characters) using the keypad.
5. Press **Right Soft Key** for **Options** and select from **Insert Quick-Text** (1) or **Insert Signature** (3).
6. Once your message is complete, press **OK**.
7. Press **Left Soft Key** for **Send**.

Note: The ability to send text messages are subject to network service availability.



Changing the Wallpaper Image

1. From the **Settings (8)** menu, select **Display (2)**.
2. Select **Screens (3)**.
3. Select **Wallpaper (1)**.
4. Select from the list of default images or press **right** or **left** on the Navigation Key for downloaded images and press **OK**.
5. Press **Left Soft Key** for **Save**.

Changing the Call Ringer

1. From the **Settings (8)** menu, select **Sounds (1)**.
2. Select **Ringers (1)**.
3. Select either **Caller ID (1)**, **No Caller ID (2)**, or **Restricted Calls (3)**.
4. Select from the list of available ringers and press **OK**.


PERSONAL INFORMATION TOOLS



THE SCHEDULER

Scheduling an Event

1. From standby mode, press the **Schedule** icon (up) on the Navigation Key.
2. Highlight the event date using your Navigation Key and press **Left Soft Key** for **Add**.
3. You may set the appropriate start and end times, content, voice memo, recurrence (if any) or alarm & ringer by scrolling to the corresponding field, entering the desired information, and pressing **OK**.
4. Press **Left Soft Key** for **Save**.



Composing a Voice Memo

1. From standby mode, press and *hold* the side **Voice Memo Key**.
2. Start recording after the tone.
3. Press **Left Soft Key** for **Done** to stop recording. By default, your message will be listed by date and time.

Note: Recorded voice memos can be found in the **Tools (7) > Voice Memo (3)** menu.

CONTACTS

The internal phone book is capable of storing up to 500 contacts with up to 5 numbers and 3 e-mail addresses per entry.



Adding a New Contact Entry

1. From the **Contacts (1)** menu, select **New Number (2)**.
2. Enter the telephone number and press **OK**.
3. Select a label (**Home**, **Home2**, **Office**, **Office2**, **Mobile**, **Mobile2**, **Pager**, **Fax**, **Fax2** or **None**) and press **OK**.
4. Enter a name for the entry and press **OK**.
5. To set the speed dial, highlight **Speed Dial** and press **OK**.
6. Enter the speed dial number (2–99) and press **OK**.
7. Press **Left Soft Key** for **Done**.
8. Add more phone numbers, e-mail addresses or press **Left Soft Key** for **Done**.

MENU TREE

CONTACTS (1)

1. List Contacts
2. New Number
3. New E-mail
4. Groups
5. Speed Dials
6. My Contact Info



- > 4. Signature
- > 5. Voice Mail #
- > 6. Auto View
- > 7. Entry Mode
- > 8. Insert Quick-Text
- > 9. Auto Play
- 7. Erase All

RECENT CALLS (2)

1. Dialed Calls
2. Received Calls
3. Missed Calls
4. Erase Calls
 - > 1. Dialed Calls
 - > 2. Received Calls
 - > 3. Missed Calls
 - > 4. All Calls
5. Call Timer
 - > 1. Last Call
 - > 2. Home Calls
 - > 3. Roam Calls
 - > 4. All Calls
6. KB Counter
 - > 1. Received
 - > 2. Transmitted
 - > 3. Total



SpeedTalk™ (4)

1. ST Contacts
2. New ST Contact
3. New ST Group
4. Recent ST
5. ST Settings
 - > 1. ST On/Off
 - > 2. Speaker On/Off
 - > 3. ST Alert Tone



easyedge™ (5)

1. easyedge
2. Help



MEDIA (6)

1. Images
2. Sounds



TOOLS (7)

1. Schedule
2. Alarm Clock
 - > 1. Alarm 1
 - > 2. Alarm 2
 - > 3. Alarm 3
 - > 4. Quick Alarm



3. Voice Memo
4. My Shortcut
5. Notepad
6. Ez Tip Calc
7. Calculator
8. World Clock

SETTINGS (8)



1. Sounds
 - > 1. Ringers
 - > 2. Key Tone
 - > 3. Volume
 - > 4. Message Alerts
 - > 5. Service Alerts
 - > 6. Power On/Off Tone
 - > 7. DTMF Length
2. Display
 - > 1. Banner
 - > 2. Backlight
 - > 3. Screens
 - > 4. Menu Style
 - > 5. Clocks
 - > 6. Theme Colors
 - > 7. Contrast
 - > 8. Fonts
 - > 9. Language
 - > 0. Power Saver
 - > *. Status Light
3. System
 - > 1. Select System
 - > 2. Set NAM
 - > 3. Auto NAM
 - > 4. Serving System
4. Security
 - > 1. Lock Phone
 - > 2. Restrict Calls

- > 3. Emergency #s
- > 4. Change Lock
- > 5. Erase Contacts
- > 6. Reset Default
- 5. Call Setup
 - > 1. Auto Retry
 - > 2. Answer Call
 - > 3. Auto Answer
 - > 4. One-Touch Dial
 - > 5. Voice Privacy
 - > 6. Auto Volume
 - > 7. TTY Mode
- 6. Data Settings
 - > 1. Data/Fax
 - > 2. PC Connection
- 7. Voice Services
 - > 1. Voice Commands
 - > 2. Sound Modes
 - > 3. Announce Alerts
 - > 4. Best Match
 - > 5. Train Words
 - > 6. Help
- 8. Location

PHONE INFO (9)



1. My Phone Number
2. S/W Version
3. Icon Glossary
4. Shortcut Help

